



ONEIDA COUNTY SHERIFF'S OFFICE



Grady M. Hartman
Sheriff

Daniel L. Hess
Chief Deputy

Weather Alert Radio Set-Up Procedures WR-100 Midland

Battery Installation

Three (3) AA alkaline batteries are used to provide back-up power to the Weather Alert Radio. The battery compartment is located in the bottom of the radio. **DO NOT USE RECHARGEABLE BATTERIES.** Batteries provide emergency power for the radio in case of a power outage!

Programming The Radio Frequency (Page 2 of Owners Manual)

- Turn **ON** Weather Radio (side of radio)
 - Press **MENU**
 - Press **UP** directional arrow until **CHANNEL** is displayed
 - Press **SELECT**
 - Press up directional arrow until you hear the broadcast of your station, then press **SELECT**
- Note: you will hear a voice broadcast when you have found your station, static is heard on channels not received in your area.
- Press **MENU** to close menu mode.

Programming Alert Type: Voice, Tone or Display (Page 9 of Owners Manual)

- Press **MENU** button to open menu options
- Press **UP** arrow to scroll through menu options until **ALT TYPE** (Alert Type) is displayed, then press **SELECT**
- Press **UP** arrow to scroll through the following alert types (Display, Voice, Tone)
- Press **SELECT** to choose the Alert Type desired
- Press **MENU** to close menu mode.

'ANY' S.A.M.E. Codes is the Default Factory Setting (Page 8 of Owners Manual)

Weather Monitor comes preprogrammed to receive NWS Weather & Hazard Alert transmissions for all S.A.M.E. county codes within range. If you want to receive all Weather & Hazard Alert transmissions within reception range, leave your Weather Monitor set to 'ANY'.

Programming Specific County Information (SAME #--Page 7 & 8 of Owners Manual)

If choosing to program specific S.A.M.E. County Code(s), follow Getting SAME County Code Instructions (Page 7 & 8) to acquire county code(s) then follow instructions listed under A Single SAME County Code. The SINGLE option for entering one county code, MULTIPLE option for multiple counties, or ANY option to reset weather radio back to ANY option listed above.

Trouble-Shooting (Page 11 & 12 of Owners Manual)

Warranty & Service (Page 16 & 17 of Owners Manual)



ONEIDA COUNTY SHERIFF'S OFFICE

Grady M. Hartman
Sheriff

Daniel L. Hess
Chief Deputy



Midland Testing Information (Page 10 of Owners Manual)

The Midland WR100 radio has been updated to have the radio respond to the weekly and monthly test with **only** the visual alert. During the test, the Advisory LED will light up and the "Weekly Test" or "Monthly Test" message will be visible on the display. The radio will **not** sound the audible alert tone to avoid giving the impression of an actual alarm. The visual response to the test is confirmation that your radio is working properly.

MONTHLY: Every Wednesday between 11:00 a.m.-11:59 a.m., there will be a test from the National Weather Service. SPECIAL TESTING: The first Wednesday of every odd numbered month, the test will be conducted between 8:45 a.m.-9 a.m.